

Chapter-5

Advance Service



Contents

Chapter 5 Advance Service

5.1 System Time	3
5.2 DNSClient	3
5.3 SNTP	4

Chapter 5 Advance Service

Advanced services include configuration of system time and time server.

5.1 System Time

1. Click Config->Advance Service->System Time

2. This page configures the system time and time zone, you can synchronize the local computer time

The screenshot shows a web interface for configuring system time and time zone. On the left is a navigation menu with the following items: System Management (expanded), System Information, Web Timeout, User Management, Port Management, Basic Service, Advance Service (expanded), System Time (selected), DNS Client, and SNTP. The main content area is divided into two sections: 'System Clock Setting' and 'Timezone Setting'. The 'System Clock Setting' section displays the current system time as 'Fri 2021/09/17 20:15:51 CCT 08:00'. It includes input fields for 'New Date' (set to 2021/1/1) and 'New Time' (set to 13:55:53), each with a 'Get From PC' button. Below these are 'Config' and 'Refresh' buttons. The 'Timezone Setting' section has a 'Zone Name' dropdown menu set to 'CCT' and a 'UTC Offset (Hours)' input field set to '8'. It also features 'Config' and 'Refresh' buttons.

System Clock Setting	
Current System Time	Fri 2021/09/17 20:15:51 CCT 08:00
New Date	<input type="text" value="2021/1/1"/> Get From PC
New Time	<input type="text" value="13:55:53"/> Get From PC
Config Refresh	

Timezone Setting	
Zone Name	<input type="text" value="CCT"/>
UTC Offset (Hours)	<input type="text" value="8"/>
Config Refresh	

Figure 5-1

5.2 DNSClient

1. Click Config->Advance Service->DNSClient

2. This page configures the IP and domain name of the time server (need to be configured in unicast mode)




Figure 5-2

5.3 SNTP

- 1. Click Config->Advance Service->SNTP
- 2. This page configures the SNTP.




Figure 5-3