

Chapter 10: MAC Address Table



Contents

| | |
|--|---|
| Chapter 10 MAC Address Table..... | 3 |
| 10.1 MAC Address Table Overview | 3 |
| 10.2 Configure MAC Address Table | 4 |
| 10.2.1 MAC Address Table Configuration Task List..... | 4 |
| 10.2.2 Configure the Aging Time | 4 |
| 10.2.3 Add MAC Address Table by Manual | 4 |
| 10.2.4 Display MAC Address Table | 6 |
| 10.2.5 Enable/Disable MAC Learning | 7 |
| 10.2.6 Quantity Limitation on MAC Address Learning Table | 8 |

Chapter 10 MAC Address Table

10.1 MAC Address Table Overview

The system maintains a MAC address table for forwarding packets. The entries in this table contain the device MAC addresses, VLAN IDs, and GPON port numbers. When a packet enters the GPON, the GPON looks up the MAC address table based on the destination MAC address of the packet and the VLAN ID of the packet. If the packet is found, the GPON sends the packets to the specified ports. Otherwise, GPON will broadcast the packets in this VLAN. The system can be able to learn MAC address table. If the source MAC address of a received packet does not exist in the MAC address table, the system will add the source MAC address, VLAN ID, and port number of the received packet as a new entry to the MAC address table.

You can manually configure MAC address entries. The administrator can configure the MAC address table based on the actual network condition, that is, the administrator can add or modify static entries, permanent entries, blackhole entries, dynamic entries.

System provides MAC address aging function. If a device does not send any packets for a certain period of time, the system deletes the MAC address entries associated with the device. MAC address aging only takes effect on the learned MAC address or the MAC address entries which can be aged (the dynamic MAC address entries).

10.2 Configure MAC Address Table

10.2.1 MAC Address Table Configuration Task List

| Configuration Task | Description | Detailed Configuration |
|---|-------------|------------------------|
| Configure the Aging Time | Optional | 10.2.2 |
| Add MAC Address Table by Manual | Optional | 10.2.3 |
| Display MAC Address Table | Optional | 10.2.4 |
| Enable/Disable MAC Learning | Optional | 10.2.5 |
| Quantity Limitation on MAC Address Learning Table | Optional | 10.2.6 |

10.2.2 Configure the Aging Time

| Operation | Command | Remarks |
|---|---|---|
| Enter global configuration mode | system-view | |
| Configure the aging time of MAC address | mac-address-table age-time { <i>agetime</i> disable } | <i>disable</i> means mac address will not be aged |
| Configure the default aging time of MAC address | undo mac-address-table age-time | 300s by default |
| Display the aging time of MAC address | display mac-address-table age-time | |
| Display the aging time of MAC address | display mac-address-table age-time | |

10.2.3 Add MAC Address Table by Manual

| Operation | Command | Remarks |
|---------------------------------|--------------------|---------|
| Enter global configuration mode | system-view | |

| | | |
|---|--|--|
| Configure the static permanent dynamic mac-address | mac-address-table { static permanent dynamic } mac-address interface ethernet interface-num vlan vlan-id | |
| Configure the blackhole mac-address | mac-address-table blackhole mac-address vlan vlan-id | |
| Delete the static permanent dynamic mac-address | undo mac-address-table [dynamic permanent static] mac-address interface ethernet interface-num vlan vlan-id | |
| Delete the blackhole mac-address | undo mac-address-table [blackhole dynamic permanent static] mac-address vlan vlan-id | |
| Delete the static permanent dynamic mac-address by port | undo mac-address-table [static permanent dynamic] interface ethernet interface-num | |
| Delete the blackhole mac-address by port | undo mac-address-table [blackhole dynamic permanent static] vlan vlan-id | |
| Delete all mac-address | undo mac-address-table | |

10.2.4 Display MAC Address Table

| Operation | Command | Remarks |
|-----------------------------|--|---------|
| Display all MAC address | display mac-address-table | |
| Display CPU MAC address | display mac-address-table cpu | |
| Display MAC address by mac | display mac-address-table <i>mac-address</i> [vlan <i>vlan-id</i>] | |
| Display MAC address by type | display mac-address-table { static dynamic permanent blackhole } [vlan <i>vlan-id</i>] | |
| Display MAC address by port | display mac-address-table { static dynamic permanent blackhole } interface ethernet <i>interface-num</i> [vlan <i>vlan-id</i>] | |
| Display MAC address by vlan | display mac-address-table vlan <i>vlan-id</i> | |

10.2.5 Enable/Disable MAC Learning

You can configure whether the device learns MAC addresses dynamically or not.

If MAC address learning is disabled under global configuration mode, all ports cannot learn MAC address; If you want to disable mac address learning on some ports, just enable MAC address learning under global configuration mode and disable MAC address learning on the port will be OK

| Operation | Command | Remarks |
|------------------------------------|--|---------|
| Enter global configuration mode | system-view | |
| Enable global mac learning | mac-address-table learning | |
| Disable global mac learning | undo mac-address-table learning | |
| Enter interface configuration mode | interface { { ethernet <i>interface-num</i> } <i>interface-name</i> } | |
| Enable mac learning | mac-address-table learning | |
| Disable mac learning | undo mac-address-table learning | |
| Display mac learning | display mac-address learning [interface ethernet [<i>interface-num</i>]] | |

10.2.6 Quantity Limitation on MAC Address Learning Table

Under port configuration mode, you can configure the maximum number of learned MAC addresses on a port. By default, the number of M

| Operation | Command | Remarks |
|-------------------------------------|--|---------|
| Enter global configuration mode | system-view | |
| Enter vlan configuration mode | vlan <i>vlan-id</i> | |
| Configure max-mac-count | mac-address-table max-mac-count <i>max-mac-count</i> | |
| Configure the default max-mac-count | undo mac-address-table max-mac-count | |
| Enter interface configuration mode | interface { { ethernet <i>interface-num</i> } <i>interface-name</i> } | |
| Configure max-mac-count | mac-address-table max-mac-count <i>max-mac-count</i> | |
| Configure the default max-mac-count | undo mac-address-table max-mac-count | |
| Display the max-mac-count | display mac-address max-mac-count { interface ethernet [<i>interface-num</i>] vlan <i>vlan-id</i> } | |